



**NOTES:**

1. INSTALL BACKFLOW PREVENTOR AS REQUIRED BY LOCAL CODES AND HEALTH DEPARTMENT. VERIFY LOCAL REQUIREMENTS PRIOR TO INSTALLATION.
2. INSTALL FREEZE PROTECTION JACKET AND CAGE. SEE CITY STANDARD DETAIL LSD-17 FOR CAGE DETAIL.
3. REFER TO CITY STANDARD DETAIL LSD-14 FOR ALL MATERIALS

			<div>CITY OF FREMONT</div> <div>STANDARD DETAILS</div> <div>CITY STANDARD IRRIGATION</div> <div>BACKFLOW PREVENTOR UNIT</div>				DATE APPROVED BY CITY COUNCIL	
							04/11/06	
							RESOLUTION NO. 2006-31	
							<div>Nam Hughes</div>	
NO.	REVISED	DATE					CITY ENGINEER	
REVISIONS								
FILE NO.		SCALE	DRAWN	CHECKED	DATE	DWG NO.		
LSD-16.DWG		1" = 1'-0"	AK/MM/PM	RER	NOV. 2005	LSD-16	16 of 27	